


HDVS-RX firmware update process


Please see the following for the update instruction.

Attached is a picture of two different hardware. Based on the information highlighted, you should update them accordingly.



The steps to update the firm is as follows:

1. Make sure the HDVS-Rx is disconnected from power.
2. Hold the Menu button on the HDVS-Rx while plugging in the USB cable that is connected to your computer.
3. You should get a popup window showing USB update.



4. Open the folder and drag the attached bin file to this folder.
5. Once file transfer is complete, you can disconnect the USB cable and repower the RX.
6. Verify your firmware by hitting menu on the RX.
7. Go to information
8. At the bottom of the OSD menu will list the Tx and Rx firmware version.